

THE DRIVER GEAR

The Trucker's Winter Survival Playbook (2026–27)

Everything in the free winter cab checklist, plus the math, the product picks, and the what-to-do-when-it-goes-wrong — the stuff that doesn't fit in a blog post.

From The Driver Gear — research-based gear guides for truck drivers. Written in Canada, for North American roads.

How this playbook was made: Every number, product, and recommendation in these pages comes from The Driver Gear's published winter guides — scored from manufacturer specs and verified buyer reviews, not from hands-on testing. We say so plainly on the site and we say it here. Prices are in Canadian dollars, as recorded in October 2026, and they move — confirm before you buy. Nothing in this playbook is an affiliate link.

Contents

1. The October Winterize — the four-week countdown
2. Heat Without Idling — the fuel math, real numbers
3. The 12V Budget — watts, fuses, and the two limits

4. The Sleeper Cab Sleep System — mattress, blackout, noise, temperature
5. Eating on the Road in Winter — cooler vs fridge, three hot meals from 12V
6. When It Goes Wrong — gelled fuel, dead batteries, frozen locks, whiteout parking
7. The Picks — 15 winter products that earned it
8. Printable Checklists — pre-trip check, emergency kit inventory, fuel-stop routine



1. The October Winterize

Winter doesn't ambush anyone. It sends the same invitation every year, and the drivers who answer it in October spend January driving while everyone else spends January troubleshooting. Every item below is a service call in October and an emergency in January. Run them in order — four weeks, one job per week, done before the first hard freeze.

Week 1 — Confirm your heat

Fire up the bunk heater for a full night. Not five minutes in the yard — a full night, the way you'll actually use it. A diesel bunk heater that dies in October is a service call; a heater that dies in January is an emergency, forty kilometres from the nearest town on the coldest night of the year.

While it's running, listen for what's wrong: a fuel pump that's gone loud, a controller throwing fault codes, ducting that's come loose. If your truck doesn't have a bunk heater, this is the week to decide your plan — heater, blanket, or idle — because deciding in January means deciding cold. (Chapter 2 does the full math.)

Week 2 — Sort your plug-in plan

Know where your shore power comes from before you need it. If you park where plugs exist, confirm the block heater actually works — a dead heater you discover at 4 a.m. in Grande Prairie is a very expensive lesson. Put the block heater and battery blanket on a heavy-duty outdoor timer so they warm the engine for 2–3 hours before departure instead of burning power all night. Carry a spare extension cord rated for the cold; cheap cords crack and fail exactly when you need them.

Battery health check happens this week too. Weak batteries that "got through last winter" will not get through this one. Load-test before November.

Week 3 — Fit your chains

Size chains to the sidewall, practice once in the yard, and carry them before you need them. British Columbia's chain-carry season starts October 1 — if you run the Coquihalla, the chains ride with you from this week on. Practicing in a dry yard in October is a fifteen-minute job. Learning on a snowy shoulder in January is a different story.

Week 4 — Treat the fuel and load the kit

Start anti-gel before the cold snap, not during it. Preventative additive goes in the tank at fill-up; the rescue bottle lives in the side box all winter. Know your fuel's cloud point — winter-blend diesel from the pump helps, but a -30°C (-22°F) night two provinces from where you fuelled can still gel a truck.

Then load the emergency kit: boots, sleeping bag, food, water, a charged phone, hand warmers in the door pocket. Pack it before the storm, not during. The full inventory is in Chapter 8 — print it and work down the list.

Why October, specifically

The first hard freeze usually lands in October, and everything gets harder after it. Installation is the real lead time: a bunk heater ordered after the first -30°C (-22°F) overnight is a heater installed in a cold yard, if you can get a shop slot at all. Heaters and blankets are once-a-decade purchases — buying before demand spikes is the cheap insurance play.

October is also when the practice happens. Chains practiced once in a dry yard take fifteen minutes to learn. The bunk heater's full-night test happens while a failure is still a service call. The block heater's timer gets programmed while you can feel your fingers. Every one of these jobs is pleasant in October and miserable in January — that's the entire argument.

The October shopping list

If you're starting from zero, here's the buy order — heat first, because everything else is comfort and this is survival:

1. **Bunk heater service or decision** (Week 1). Service call now, or commit to the blanket-plus-layering plan from Chapter 2.
2. **Block heater + battery blanket + outdoor timer** (Week 2). The timer is the part drivers forget — a heavy-duty outdoor timer, not a household one.
3. **Chains** (Week 3). Sized to the sidewall. BC's season starts October 1.
4. **Fuel treatment** (Week 4). Preventative for the tanks, rescue bottle for the side box.
5. **The kit** (Week 4). Sleeping bag, boots, shovel, warmers, flares — Chapter 8's inventory, bought once and checked yearly.

That's the month. Four weeks, five jobs: heat confirmed, plug-in plan sorted, chains fitted, fuel treated, kit loaded. Do this and winter mostly takes care of itself.

2. Heat Without Idling

The fuel math, with real numbers

An idling heavy truck burns roughly 3.0 litres (0.8 US gal) of diesel per hour. Over a 10-hour rest, that's about 30 litres (7.9 US gal) a night. At C\$2.70/L, one night of idling for heat costs about **C\$81**. Run that five nights a week across twenty winter weeks — 100 nights — and you've burned roughly **C\$8,100 in diesel while parked**. (Pump prices move; the litres don't. Run your own price through the same arithmetic.)

Now the alternative. A current-generation diesel bunk heater — an Espar-class unit — burns 0.10–0.27 litres per hour. That's roughly 2 litres (0.5 US gal) over a full night: about **C\$5** at the same pump price. Same warm sleeper. Sixteen times cheaper.

That's the whole chapter in two paragraphs, but the details matter, because "just buy a heater" skips the part where you have to choose between four different answers.

The four answers, compared honestly

Idling: the expensive default. It works — that's its only virtue. About 30 litres a night, plus soot buildup, oil dilution, shorter service intervals, and idling fines. Many Canadian municipalities limit idling to 1–3 minutes, with Toronto allowing about one minute per hour on the busiest freight corridor. US drivers face state and city rules too, with California and several northeastern states the strictest. Idling is the fallback every driver should have, and the plan no driver should rely on.

Diesel bunk heater: the standard answer. A small furnace plumbed into the sleeper — Webasto and Espar are the names you'll hear — burning diesel from your tanks through a heat exchanger and blowing warm air into the bunk. It holds the whole sleeper through a -30°C (-22°F) night on a rounding error of fuel. The catch is installation and maintenance: it has to be installed, serviced on schedule, and tested for a full night in October. The number-one winter rule applies — a heater that dies in October is a service call; in January it's an emergency.

APU: heat plus power, at a price. An auxiliary power unit is a small diesel engine mounted on the truck that generates electricity and heat without running the main engine. It charges your batteries, runs the HVAC, and powers cab appliances — the full hotel load — on a fraction of idling's fuel. The catch is the

price tag: several thousand dollars installed, plus its own maintenance schedule. APUs make sense for owner-operators running year-round and for fleets spec'ing trucks. They are rarely something a company driver chooses, and you are not buying one off Amazon.

12V heated blanket: personal warmth, small draw. A 12V-native blanket draws roughly 45–50W — about 4 amps — and warms the person under it, not the cab around them. On a night when the bunk heater is struggling, or when you're caught without one, it's the difference between sleeping and shivering. Buy 12V-native (a 120V throw through an inverter pulls nearly triple the amps for the same warmth — about 11 amps versus 4, roughly 88Ah versus 32Ah over an 8-hour night). Get one with a published auto-shutoff timer and a fused plug. Run it on a timer so it's not pulling all night.

The verdict the site has held across every guide: **bunk heater as the plan, 12V blanket as the insurance.** In a straight fight for keeping a sleeper livable at -30°C (-22°F), the heater wins walking away. The blanket wins the only contest it enters: cheapest backup warmth you'll ever buy.

Choose your answer

Not every driver gets to choose the "right" answer — equipment, money, and whose truck it is all vote. Here's the honest decision tree:

- **Your truck has a bunk heater:** service it, test it in October, run it. You're done — the blanket is your insurance for the night it dies.
- **Company truck, no heater, and no say:** the 12V blanket on a timer plus the layering play below. It won't heat the cab, but it will keep *you* warm, and it's the only answer that fits a truck you don't own.
- **Owner-operator, no heater yet:** run the fuel math above. At roughly C\$81 a night to idle versus C\$5 on a bunk heater, the heater pays for itself in weeks, not years — even before the anti-idling fines.
- **Anyone, any truck:** the blanket anyway. It's \$35–\$65, it lives in the side box, and it's the backup for every other plan's worst night.

The layering play

Veteran winter drivers layer heat the way hikers layer clothing. When the heater isn't enough — or on the night it picks to die, which per Murphy will be the coldest night of the year:

- A sleeping bag rated for -30°C (-22°F) over the bunk mattress.
- Bunk curtains closed to shrink the heated space.

- A mylar emergency blanket as a final layer — ugly, crinkly, and shockingly effective.
- Heavy socks and a toque for the 3 a.m. bathroom run.

None of this replaces a working bunk heater. All of it together can carry you through the night the heater picks to die.

The carbon monoxide warning

Never run an unvented combustion heater — propane buddy heaters, catalytic heaters, candles for warmth — in a sealed sleeper. Carbon monoxide is colourless, odourless, and it kills drivers every winter. A diesel bunk heater is vented to the outside by design; a propane heater from the camping aisle is not. If your heat source has a flame and no exhaust pipe leaving the cab, it does not belong in the cab. No exceptions, no "just for a few minutes."

3. The 12V Budget

Your 12V outlet will happily charge your phone, run a compressor fridge, and warm a heated blanket — but plug in a kettle or a 300W inverter and you will blow the fuse. Two different limits are in play, and mixing them up is how drivers end up with dead batteries at -20°C (-4°F) or a melted socket. This chapter is the whole electrical education in one place.

The two limits — don't mix them up

Limit 1: overloading the circuit. The outlet sits on a circuit protected by a fuse — usually 10 to 15 amps, up to 20 in some heavy-duty trucks. Draw more than the circuit allows and the fuse blows: outlet dead until you replace it. This limit is about *this instant*, engine on or off. "10 to 15 amps" is a range, not your number — your truck's fuse panel or owner's manual lists the actual rating. Check it once and write it down.

Limit 2: draining the battery with the engine off. Most highway trucks carry 3 to 4 large 12V batteries wired together — roughly 300–400 amp-hours total. But those are *starter* batteries, built to deliver a huge burst and then be recharged. They're not deep-cycle batteries, and they don't forgive deep drains. Drain them too far and the truck won't start — and repeated deep drains wear them out early. This limit is about *time*, not the fuse.

And winter makes the second limit brutal: at -30°C (-22°F), a lead-acid bank delivers roughly **half** its rated amp-hours. Your 400Ah bank is effectively a 200Ah bank on a January night — and about half of that is the half you shouldn't touch. Plan around only half the bank's usable capacity for parked accessories, and less if the batteries are older.

The only math you need

Watts $\div$ 12 = amps. That's it. A 60W blanket is 5 amps. A 150W inverter is 12.5 amps.

Three reference numbers to memorize:

- **180W** — the ceiling on a 15A fuse ($12\text{V} \times 15\text{A}$).
- **144W** — the 80% rule: safe continuous draw on a 15A fuse is about 12 amps. Treat it as a starting point, not a standard — your manual beats any rule of thumb.
- **300–400Ah** — typical 3–4 battery bank; plan around half of it parked.

What each device actually draws

Device	Typical draw	Amps at 12V	Rough parked drain	Verdict
Phone/tablet charger	10–20W	~1–1.5A	Small	SAFE — negligible
Laptop via 150W inverter	70–90W	~6–7.5A	~50–60Ah over 8 hrs	SAFE driving; moderate parked
12V compressor fridge (40–50L)	~50W cycling	~4A while running	~10–15Ah overnight	SAFE with battery protection set
12V heated blanket	45–60W	~4–5A	~32–40Ah over 8 hrs	SAFE on the circuit; use a timer
Dashcam / small cab fan	<12W	<1A	Small	SAFE
300W+ plug-in inverter	300W+	25A+	—	BLOWS a typical 15A fuse
Electric kettle	1000–1500W	80–125A	—	NO — needs hardwired inverter
Microwave	800–1200W	65–100A	—	NO — needs hardwired inverter
120V space heater	750–1500W	60–125A	—	NO — plus a cab fire risk

Draws are typical values — your devices and your truck will vary. The fridge number assumes a compressor cycling, not running flat out.

Two things worth noticing in that table. First, the compressor fridge is the one bigger load you can reasonably run parked — but only with its low-voltage battery protection set to medium or high on starter batteries. In winter, set it to high: the fridge cutting out at 3 a.m. is an inconvenience; a truck that won't start at -35°C (-31°F) is a safety problem. Second, a thermoelectric cooler — the cheap kind — draws 4–5 amps *continuously* with no thermostat and no cutoff: 40–50Ah overnight, versus 10–15Ah for a compressor. In winter it will also freeze your drinks in a heated sleeper. Winter alone justifies a compressor fridge.

The five rules

Rule 1: nothing with a heating element goes in the lighter socket. Kettles, microwaves, hair dryers, 120V space heaters — 60 to 125 amps. The fuse blows instantly. If you need that kind of power, the answer is a large inverter wired directly to the batteries with correctly sized wire and fusing, installed by someone who does vehicle electrical. Not a plug-in unit.

Rule 2: never plug a 300W+ inverter into the outlet. 300 watts at 12 volts is 25 amps — nearly double a typical 15-amp fuse. It blows on the first real load. Around 150W is the practical maximum for a plug-in inverter, and even then, check your truck's fuse rating first. (A 200W "personal heater" from the socket is still no — 200W is over the ~150W fused ceiling, and 17 amps all night is real drain.)

Inverter sizing, without the guesswork

If your plans need more than the socket gives — a microwave, an air fryer, real cooking — the answer is an inverter wired directly to the batteries. Size it from the appliance's *input* watts, not its label watts, and then add headroom for startup surge:

- **700W microwave:** pulls about 1,050W input, with a magnetron startup surge two to three times that. Driver-tested answer: a **1,500–2,000W continuous pure-sine inverter**, hardwired with heavy cable and a fuse. A 1,000W plug-in unit will fault on the surge.
- **900W air fryer:** roughly 85 amps from the battery side. Realistically a **1,500W+ continuous inverter**, hardwired — and only run it with the engine on or on shore power. Twenty minutes at 85A is a real bite out of a battery bank.
- **Pure sine matters.** On modified sine, a microwave can cook at roughly half power while still pulling full draw from the batteries. Pure sine is the honest pairing.

And the non-negotiables: heavy cable, correct fusing, installed by someone who does vehicle electrical. A few hundred dollars at a shop against a burnt truck. Never a plug-in unit for these loads, never hardware-store wire tapped to battery cables.

Rule 3: respect the parked clock. While the engine runs, the alternator covers everything — charge freely. Parked, every amp-hour comes from the bank. Phone chargers and a dashcam can run a long time. A fridge overnight is fine with battery protection on. A heated blanket plus a fridge for a full parked weekend on old batteries is how you end up calling for a boost at -20°C (-4°F).

Rule 4: never modify the protection to fit the load. Bigger fuses, bypassed fuses, rewrapped fuse wire, tapping battery cables with hardware-store wire — that's how cabs catch fire. The fuse is sized to protect the wire. Upgrading the fuse without upgrading the wire just moves the failure point into your wiring. A fuse that keeps blowing is a warning, not an annoyance.

Rule 5: don't run damaged gear. Frayed cords, cracked plugs, a heated blanket with worn spots, an inverter that smells hot — retire them. Reseat every 12V plug the first week of cold weather: cold makes plastic brittle and connections loose, and a wobbling plug arcs.

One habit from the site's reviewers: do the math once, then label it. Tape near the outlet with each device's amp draw — phone charger 2A, blanket 5A, fridge 4A while running. When you can see the numbers, you stop guessing, and you stop blowing fuses in truck stops at midnight.

4. The Sleeper Cab Sleep System

Sleep in a truck is a system with an order of operations. Do it in this order — mattress, darkness, noise, temperature — because each layer only works once the one before it is handled. A \$400 mattress can't fix a lit bunk, and blackout curtains can't fix a pad that's compressed into a board.

Step 1: the mattress

Your factory bunk pad is the weakest link in your sleeper — a hard slab that saps a recovery night. Drivers report waking up sore in the shoulders and hips from a pad that's compressed into a board, and a tired driver is a slow driver.

Measure before you buy anything. There is no single standard bunk size. Lower bunks in many North American sleepers accept a twin XL (38" × 80"), but upper bunks are often shorter and narrower — some aren't even a straight twin. Write down three numbers: width (board edge to board edge, at the narrowest point), length (head to foot), and clearance above the pad (sit up on the bunk and check — a 3-inch topper eats headroom fast under a cabinet or on a top bunk). Measure the bunk board itself, not the old pad, which may have shrunk or curled. Order to your three numbers.

The cheap fix works. A 2–3 inch memory foam topper over a decent-but-hard pad changes the whole night for under \$100 CAD. If the pad underneath is truly finished — craters, not just firm — a full replacement in twin or twin XL runs roughly \$125–\$220 CAD. A topper is forgiving (you can trim foam with a sharp utility knife along a straight edge); a mattress is not.

Memory foam sleeps hot — plan for it. Dense foam traps body heat: free insulation under you in January, a griddle in July — especially paired with a heated blanket or a warm cab. What actually helps: a breathable cotton or bamboo cover instead of a plastic-feel protector, cracking the bunk window or running the 12V fan for airflow, and going 2 inches instead of 3 if you run hot. Gel-infused and ventilated designs blunt the heat at the margins.

Step 2: darkness

Daylight is the cheapest sleep problem to fix, and no mattress compensates for a lit bunk — your body won't make melatonin properly in a lit bunk. The good news: total darkness costs almost nothing.

Find the leaks before buying anything. In daylight, close every curtain and shade, climb into the bunk, and wait two minutes for your eyes to adjust. You'll see exactly where light comes in — usually the curtain edges, the gap where two curtains meet, and around the windshield. You're not buying "blackout"; you're buying fixes for three specific gaps.

Fix the curtains you have. Sleeper curtains fail at the edges, not the middle: overlap panels generously (10–15 cm / 4–6 in kills the center gap), rehang sagging hooks, and pin edges with adhesive Velcro dots where light sneaks around the sides. If the curtains are thin enough to glow, doubling them beats replacing them — hang a dark blanket behind the existing one. Ugly, effective, free.

The windshield is the big one. It's the largest pane and the hardest to curtain — and where morning sun hits first. A fitted reflective shade pressed against the glass blocks most of it, and doubles as cab insulation in both summer heat and winter cold.

The cheapest complete fix is a sleep mask — total darkness for almost nothing, anywhere you park.

Step 3: noise

Foam earplugs are the cheap answer — they take the edge off engine and road drone, not every sound. Many drivers prefer a Bluetooth sleep headband playing low white noise: it survives eight hours without hurting, and sudden changes still register. Nothing here replaces the truck's alarms — and never sleep through a mandatory check.

Step 4: temperature

Cold and dark beats warm and stuffy — bunk curtains plus the bunk's own vents beat a sunlit box. In winter this is easy: the bunk heater holds the sleeper, the blanket holds you, and the bag (below) is the insurance. In shoulder seasons, a 12V bunk fan moves air without the power cost of anything bigger.

The winter bag rule: buy 10–15°C colder than your worst night. A "–20°C" bag keeps you alive at –20°C; comfort sits roughly 10–15 degrees warmer. For –30°C (–22°F) prairie nights, that means a –30°C-rated bag — or a lighter bag layered with the 12V blanket from Chapter 2. On fill: down packs smaller and lasts longer, but loses most of its insulation when damp — and a winter cab is a damp place. Synthetic keeps working damp. If you're broad or tall, size up; the small weight penalty beats a cold night.

Manage the temperature split. The sleeper stays cold and dark for sleeping; the cab stays comfortable for driving — bunk curtains and separate vent control are the answer. A 12V bunk fan moves air in the shoulder seasons without the power cost of anything bigger, and cracking the bunk window a finger's width keeps condensation from frosting everything by morning.

The order matters: mattress first, then darkness, then noise, then temperature. Skip the order and you'll buy the wrong fix twice.

5. Eating on the Road in Winter

Truck-stop meals are one of the biggest leaks in a driver's budget. A 12V cooler or fridge means cold water, packed lunches, and groceries that survive a multi-day run — and in winter, the cold changes the rules for every appliance involved. Cooking in the truck is a power question before it's a food question, so this chapter starts with the hardware and ends with three actual hot meals.

Cooler vs fridge: winter settles the argument

A thermoelectric cooler only cools about 22°C (39.6°F) below the air around it, and it runs constantly — no thermostat, no off switch. A compressor fridge holds the temperature you set, can freeze, and cycles on and off, using fewer watt-hours per day despite stronger cooling.

Summer forgives the thermoelectric. Winter exposes it twice over:

1. **In a heated sleeper**, an 18°C (64°F) cab puts the thermoelectric at roughly -4°C (25°F) inside — your "cooler" is now a freezer you can't control. Drinks burst, produce freezes, and you have no thermostat to fix it.
2. **On the battery**, the thermoelectric pulls 4–5 amps all night — 40–50Ah — with no low-voltage cutoff. The compressor sips 10–15Ah over a 10-hour rest and shuts itself off before your batteries drop too far.

The site's verdict, held across three guides: the thermoelectric is the cheapest honest way to keep drinks cold on day shifts; the compressor is the sweet spot for overnights; and winter alone justifies the compressor. Keep the unit in the sleeper — the warmest, most stable part of the truck — and never leave any cooler in an unheated cab or exterior compartment at -30°C (-22°F).

The power rules for cooking

A 12V socket circuit is fused at about 15 amps — roughly 180 watts — and anything over about 150 watts has to be hardwired to the battery bank, never run off the lighter socket. That single fact sorts every cooking appliance:

Method	Power draw	What it needs	About
12V lunchbox oven	~9A peak (108W)	Just the 12V socket	~\$60 CAD
12V slow cooker	Low draw	Just the 12V socket	~\$75 CAD
Microwave (700W cooking)	~1,050W input, ~100A from batteries	1,500–2,000W hardwired pure-sine inverter	~\$80–\$130 CAD
Mini air fryer (900W)	~85A from batteries	1,500W+ inverter, engine on or shore power	~\$69 CAD

(Prices as recorded October 2026; they move.)

The brutal version: cooking watts are not input watts. A 700W-cooking microwave pulls over 1,000W to make that heat, and the magnetron's startup surge can briefly reach two to three times that — which is why the driver-tested answer is a 1,500–2,000W continuous pure-sine inverter, hardwired with heavy cable and a fuse. On modified sine, a microwave can cook at roughly half power while still pulling full draw — pure sine is the honest pairing.

The timing rule: high-watt appliances are drive-time appliances. A microwave or air fryer running off the inverter is really running off the alternator — which means the engine is turning. Cook while you roll, eat when you park. The 12V lunchbox oven and slow cooker are the opposite: socket-powered, low-draw, happy to run for hours with the engine off. Pick your appliance by *when* you want to eat, not just what you want to cook.

Three hot meals from 12V

Meal 1 — The lunchbox dinner. The Koolatron-style 12V lunchbox oven heats to 300°F (149°C) — enough for foil-pan meals, canned food, pizza, and burgers, straight from the 12V socket. Plug it in at a fuel stop, not when you're already hungry: a lunchbox oven is not a microwave — think tens of minutes, not minutes. Foil-pan chicken thighs and vegetables, loaded before your last fuel stop, are hot when you park. Keep it upright (the manufacturer warns it can leak if knocked over) and let it cool before stowing. Do not use it while driving — the manual says cook at stops and breaks.

Meal 2 — The slow-cooker shift. A 1.5-quart 12V slow cooker warms and cooks between 140°F and 170°F — a stew-and-chili machine, not an oven; it won't crisp or brown anything. Load it at the start of your shift and eat hot chili at the fuel stop. It's the true set-and-forget: removable stoneware crock, hours of

unattended cooking, dinner waiting when you park. Plan the day around it — great for dinner, useless for a quick lunch.

Meal 3 — The reheat. Last night's leftovers, back in the lunchbox oven. This is the highest-value meal in the chapter: the food is already paid for and cooked, the power cost is one socket, and it beats a truck-stop counter on price, health, and time. Pre-chill ingredients before you roll so the fridge barely works on day one, and keep the cooler in the sleeper where the temperature is stable.

Three meals, two socket-powered appliances, zero inverter. That's winter eating solved for the price of the groceries.

The winter eating rules

Winter changes the food game in three specific ways, and all three are in your favour if you plan for them:

1. **The cold is a second fridge.** A sealed container in an unheated exterior compartment stays frozen solid — free cold storage, as long as nothing in it can burst. (Never put the *cooler itself* out there at -30°C — electronics and plastics don't survive it.)
2. **Pre-chill before you roll.** Load already-cold drinks and food from the house so the compressor barely works on day one.
3. **Keep the cooler in the sleeper.** It's the warmest, most stable part of the truck — and with the bunk heater running, the fridge never actually experiences the -40°C outside.

Eat from the cab and the truck-stop leak closes. The appliance pays for itself; the habit pays for the appliance.

6. When It Goes Wrong

Winter finds the weak link every year: the battery that was fine in October, the tire pressure that bled off a few PSI, the fuel that gelled two provinces from where you bought it. This chapter is the four failures, in the order they'll find you, with the fix for each.

Gelled fuel

Diesel contains wax. As temperatures fall, wax crystals grow and the fuel thickens until it won't flow — first the filters clog and the engine stumbles, then nothing moves. The temperature where it starts is the cloud point, and on the Prairies in January it is not theoretical. Winter-blend diesel helps, but a -30°C (-22°F) night in northern Alberta can gel a truck that fuelled up in milder weather two provinces back.

Fuel treatment is **two different jobs**, and mixing them up is the most expensive mistake in this category:

- **Preventative** goes in the tank *before* the cold — at every winter fill-up. It keeps wax crystals small so fuel keeps flowing. Howes Diesel Treat (treats up to 320 gallons per 64 oz jug — a full semi fill with room to spare) also removes water and prevents deposits. STA-BIL Diesel Winter is the compact option: anti-gel to -40°F with a -36°F cold-filter plugging point reduction, in a 591 mL bottle that fits any side box — though at 150 gallons per bottle, a full semi fill needs two.
- **Rescue** re-liquefies fuel that has *already* gelled and de-ices frozen filters. Power Service Diesel 911 (80 oz jug, treats up to 250 gallons) is the only true rescue formula in the site's scoring — and it does not prevent gelling. Pouring a preventative into a gelled tank and waiting for a miracle is how drivers buy tow trucks.

Size the bottle to your tanks: two 120-gallon tanks are 240 gallons of fuel. And remember water is half the problem — frozen filters often start as water in the fuel, which is why the preventatives above handle water too.

Keep a rescue bottle on the truck all winter. Gelled fuel at -30°C (-22°F) on a dark shoulder is a tow-truck call — and the bottle belongs in your winter emergency kit, not your memory.

Dead batteries

Cold halves your capacity, thickens your oil, and stiffens every moving part at the same time. The margin you had in July is gone in January. Three layers of defence:

1. **Don't get there.** Block heater plugged in 3–4 hours before a cold start (an application-specific immersion heater is the single best defence against a -30°C (-22°F) no-start — match it to your exact engine model, never buy "universal"). Battery blanket on the bank keeps cranking amps where they belong. Both on a timer, both confirmed working in October.
2. **Carry the rescue.** Heavy-duty booster cables for the day no power station can crank a cold diesel — or a dedicated jump pack. A portable power station (268Wh class) will run a heated blanket about four hours and charge phones for days, but it will *not* crank a diesel — don't confuse the two jobs. And store the power station in the heated cab: lithium batteries won't accept a charge below about 0°C (32°F).
3. **Know the numbers.** A resting bank below about 12.0V at room temperature is already weak; at -30°C (-22°F) the same battery delivers roughly half its rated capacity. Anything drifting toward 11.5V overnight deserves attention before morning.

Frozen locks and seals

The site covers this one briefly but the fix is cheap: door seals, window seals, the gap where the curtains meet. A tube of weatherstripping beats idling all night — and sealed doors are doors that still open in the morning. Keep the sleeper's condensation plan running (crack a vent, wipe down in the morning, never store wet clothes in the sleeper), because the moisture that frosts your windshield overnight is the same moisture that glues your door seals shut.

What actually freezes in a parked cab: more than you'd think. Your water bottles, your cooler, and your windshield don't care about your heated blanket — the blanket warms you, not the cab. Wiper blades freeze to the glass, door seals glue themselves shut, and DEF (diesel exhaust fluid) freezes too. The rule is simple: if the heater isn't protecting it, assume the cold owns it. Water lives in the sleeper, wipers get lifted or covered, seals get weatherstripped in October.

Whiteout parking

When the highway closes and you're on the shoulder in blowing snow, the job is simple: stay warm, stay visible, stay put.

- **Stay warm:** the 12V heated blanket is the highest-leverage winter item you can carry — if the engine dies at -30°C (-22°F), it's the difference between an uncomfortable night and a dangerous one. The winter sleeping bag is the no-power backup: warmth that can't run out of charge.

- **Stay visible:** LED road flares punch through blowing snow where reflective triangles go invisible — flashing LEDs cut through whiteout that swallows passive reflectors, and a magnetic base means less walking on an icy shoulder at night. Carry both if you have space: triangles never run out of batteries.
- **Stay rolling after:** cold air steals tire pressure, and a soft trailer tire turns a slow morning into a roadside call. A heavy-duty inflator with battery clamps (150 PSI territory) tops up cold-stolen PSI fast — a cigarette-lighter inflator can't feed that kind of draw.

And if you're still rolling when the whiteout hits, the site's driving technique guide holds three rules above everything else: **slow down** (on ice there is no speed that's "safe enough" — only slower, and stopped); **double your following distance** and never travel in packs; and **hands off the automation** — no cruise control on ice, ever, and no Jake brake on ice either. If you can't see the road, slow down immediately and get fully off the travel lane — hazards on, well clear of traffic. Never stop in a lane in a whiteout; the driver behind you can't see you either. Stay with the truck, keep the fuel above half a tank on storm days, and tell dispatch where you are. Waiting out a whiteout is a professional decision — the freight will wait, and no load is worth the ditch.

When chain laws are posted, chain up or park. There is no third option that ends well — and your first chain-up should not be in a blizzard on a mountain shoulder, which is why Chapter 1 made you practice in October.

The rest of the kit, as the site's emergency guide lists it: collapsible snow shovel, chemical hand and foot warmers (bulk box in the door pocket — they work when everything electrical has given up), wool blankets, headlamp, snacks and water, diesel anti-gel additive. Around C\$650 at current prices for the core four; one avoided tow pays for all of it.

7. The Picks

Fifteen winter products that earned it — every one scored by the site's system from published specs and verified buyer reviews (scores out of 20), with the one-line reason each made the cut. Prices are in CAD as recorded in October 2026; they move, so confirm before you buy. No links here — search any name and you'll find it.

How the scoring works: the site scores each product out of 20 on the specs that matter for its category — published wattage and safety features for blankets, cold ratings and treat rates for additives, bunk fit and materials for mattresses — cross-checked against verified buyer reviews. Nothing is hands-on tested, and the site says so on every page; scores are provisional and move when new data arrives. The picks below are the top scorers in each winter category, not a complete catalogue.

Heat

1. **Espar Airtronic AS3 D2L 12V** — 1,525–1,595 CAD (Oct 2026) — *17/20*. The heater the rest of the bunk-heater market benchmarks itself against: 0.85–2.2 kW stepless, 0.10–0.27 L/hr published fuel burn, brushless motor, quieter fuel pump, automatic altitude compensation to ~4,000 m — relevant for the Coquihalla and Rogers Pass.
2. **Akozon 12V fleece travel throw** — 35.31 CAD (Oct 2026) — *15/20, Best pick*. The only blanket in the roundup that publishes its actual draw (43–47W, 3.8–4A) with digital temperature control and a 10–60 minute timer — the safest documented choice for a fused 12V socket.

Sleep

3. **Linenspa 2" Gel Memory Foam Mattress Topper — Twin XL** — 45–65 CAD (Oct 2026) — *15/20*. The cheapest fix on the list: gel-infused foam that turns a hard-but-intact fleet pad into a sleepable surface, with the deepest published review base of any pick here (about 4.3★, 127,000+ ratings).
4. **Yanes Yukon –30°C winter mummy sleeping bag** — ~120 CAD (Oct 2026) — *15/20, Best pick*. A Canadian –30°C synthetic mummy from a Quebec outdoor retailer — the warmest honest rating in the guide at the lowest price, and the no-power backup that can't run out of charge.

Food and power

5. **BougeRV 23 Quart Portable Car Fridge** — 230 CAD (Oct 2026) — 16/20, *Best budget compressor*. A compressor fridge with proper low-voltage battery protection at a budget price — the feature that makes overnight use a solved problem instead of a gamble.
6. **Koolatron 12V Heating Lunch Box Stove** — 60 CAD (Oct 2026) — 15/20. A real 300°F lunchbox oven off the 12V socket — no inverter, no hardwiring — from an Ontario company, with a large published base of driver reviews.
7. **BLUETTI EB3A portable power station** — 299 CAD (Oct 2026) — 16/20. The engine-off power reserve: 268Wh LiFePO4 runs a heated blanket about four hours after conversion losses, charges phones for days, and refills 0–80% in 30 minutes at a fuel stop. (4.8★, 5,722 published ratings.)

When it goes wrong

8. **Tobfit Rechargeable LED Road Flares, 4-Pack** — ~33 CAD (Oct 2026) — 15/20. Flashing LEDs punch through blowing snow where reflective triangles go invisible; magnetic base means less walking on an icy shoulder at night. IP67 sealed.
9. **Power service diesel 911, 80 oz** — *price not recorded in our October 2026 check — confirm on the live listing* — 15/20, *Best emergency rescue*. The only true rescue formula in the scoring: re-liquefies gelled fuel and de-ices frozen filters, treats up to 250 gallons.
10. **Howes diesel treat, 64 oz** — *price not recorded in our October 2026 check — confirm on the live listing* — 14/20, *Best preventative*. The preventative workhorse: anti-gel plus fuel lubrication, removes water, treats up to 320 gallons per jug — a full semi fill with room to spare.
11. **Zerostart 860-5556 heavy-duty engine block heater** — 125.61 CAD (Oct 2026) — 15/20. A 120V, 1500W immersion element threaded into the block — the proper fix for cold starts, with a stated application list (Caterpillar, Detroit Diesel, International/Navistar, Perkins). Match it to your exact engine; these are never universal.
12. **Zerostart 2800071 battery blanket, 72-inch** — 97.15 CAD (Oct 2026) — 14/20. A Thinsulate-insulated wrap built for truck battery banks in series-parallel systems — the common Class 8 layout — keeping cranking amps where they belong on the coldest mornings.
13. **ALL-TOP dual-cylinder 12V tire inflator** — 279 CAD (Oct 2026) — 14/20. 150 PSI and 350 L/min is real truck-tire territory, with battery clamps (not the outlet) and a 26-foot reach. Cold air steals pressure; this puts it back without shop air.

Feet and traction

14. **Bogs Classic Ultra Mid** — 189.93 CAD (Oct 2026) — 17/20, *Best overall*. The top-scoring winter boot in the roundup — built for fuel-island slush, icy catwalks, and -30°C pre-trip inspections.
 15. **TireChain.com 11-22.5 Cam Tire Chains (pair)** — 646.51 CAD (Oct 2026) — 15/20. Cam-style singles for 11-22.5 rubber — sized to the sidewall, practiced in the yard, carried before BC's October 1 season.
-

That's the fifteen. None of them is exotic; that's the point. Winter rewards the prepared and bills everyone else, and every item above is preparation you can buy once and use for seasons.

8. Printable Checklists

Print these. Keep them in the door pocket. Checklists beat memory at -30°C .

Pre-trip winter check

Run once in October, then spot-check monthly.

- ☐ Bunk heater fired for a full night — no fault codes, no loud fuel pump, ducting secure
- ☐ Block heater confirmed working — plugged in 3–4 hours before a cold start
- ☐ Battery blanket on the bank, on a timer
- ☐ Batteries load-tested (weak ones that "got through last winter" won't get through this one)
- ☐ Spare extension cord rated for the cold, in the side box
- ☐ Chains sized to the sidewall, practiced once in the yard
- ☐ Anti-gel in the tanks (preventative at fill-up); rescue bottle in the side box
- ☐ Tire pressures checked cold — cold air steals PSI
- ☐ Windshield washer fluid rated to -40°C , fresh wiper blades
- ☐ Door and window seals inspected — weatherstrip the gaps
- ☐ Sleeping bag rated for the real number in the sleeper (November–March)
- ☐ Heated blanket in the cab, not the trailer — timer and fused plug confirmed
- ☐ Every 12V plug reseated; cords inspected for cracking; fridge battery protection set to HIGH
- ☐ Condensation plan set: crack a vent, wipe down mornings, no wet clothes stored in the sleeper
- ☐ Windshield shade / blackout fixes in place for the bright mornings

Emergency kit inventory

Packed before the storm, not during. Check it every October.

- ☐ 12V heated blanket (fused plug, auto-shutoff timer, full-body size)
- ☐ Portable power station, charged — stored in the heated cab, not an outside box

- ☐ LED road flares (charged) + reflective triangles
- ☐ Heavy-duty tire inflator with battery clamps
- ☐ Power Service Diesel 911 rescue bottle (80 oz)
- ☐ Howes Diesel Treat or STA-BIL Diesel Winter (preventative)
- ☐ Collapsible snow shovel
- ☐ Chemical hand and foot warmers — bulk box in the door pocket
- ☐ Winter sleeping bag or wool blankets (the no-power backup)
- ☐ Headlamp
- ☐ Heavy-duty booster cables or jump pack
- ☐ Snacks and water — high-energy food, a couple of litres
- ☐ Mylar emergency blanket
- ☐ Heavy socks and toque (for the 3 a.m. anything)
- ☐ Phone charged; power bank charged

Fuel-stop routine (winter)

Every winter fill-up, same order.

- ☐ Dose the tanks with preventative anti-gel at fill-up — before the cold, not during
- ☐ Plug in the 12V lunchbox oven or load the slow cooker — eat hot at the next stop
- ☐ Top up the power station (30 minutes gets a 268Wh unit meaningfully charged)
- ☐ Walk-around tire pressure check while fuel flows
- ☐ If parked overnight on a marginal battery bank: idle 30–60 minutes mid-rest to top the bank back up
- ☐ Glance at the bunk heater controller — no fault codes before you roll into the cold

End of playbook. Drive warm.